

RAZOR™ EX Pouch Loading Protocol-at-a-Glance




1

GATHER SAMPLE



OR




OR





2

TRANSFER SAMPLE TO UNKNOWN BUFFER AND MIX SAMPLE





3

LOAD 2mL OF MIXED SAMPLE INTO SAMPLE INJECTION PORT (ORANGE LABEL)





4

LOAD 2mL OF CONTROL BUFFER INTO CONTROL INJECTION PORT (BLACK LABEL)






5

REMOVE COMB AND TWIST PLUNGERS



6

PLUNGE USING INSTRUMENT SURFACE BRACKET ON RAZOR EX



7

INSERT POUCH INTO RAZOR EX AND RUN SAMPLE

